



## The installing and using of ID programmer

1. First install the ID software “GP2012(400 V1.70) ID Programmer setup.exe” or other version.


The flow chart of installation as follow:




Choice yes and click




Choice next and click




Choice I agree and click next




Fill name and company and click next




Choice the directory and click next



Click next




Next



Finished

Run the software it will display as follow:



Read and Write is gray and cannot working.

That shows ID programmer not connected or driver not right installed.


Follow show how to install the ID programmer driver on win10 system.


## 2. ID programmer driver install




First connect ID programmer to PC USB port.

Open device manager, You will find a device as photo shows:




Right click  and choice

“Update driver software”, it will shows:



Then choice browse my computer





Fill the right driver software directory location (under installed software directory), photo shows 32 bit system, If 64 bit system the directory is X64. Click next , follow will display:



That shows driver install success. Click close to quit.

Now the read and write key become black and usable.





3. If the software running without no finding ID programming prompt.  
You can insert the ID programmer to the USB port of pager. And read or write.
4. If prompt not finding ID programmer or read or write cannot work.  
Then quit software, unconnected ID programmer with PC, reconnected again. Then run software to try.